Metal Walk-in
Chicken Coop Run

Instruction manual
For specification: 6m(L) x 3m(W) x 2m(H)

PART LIST IN BOX 1

2 x15pcs   1870mm pipe

4 x8pcs   1480mm pipe

D1 x1pcs

D2 x1pcs

**D3** x1pcs

B x6pcs

C x4pcs

D x4pcs

E x2pcs

PART LIST IN BOX 2

1 x4pcs   1410mm pipe

3 x8pcs   970mm pipe

5 x2pcs   440mm pipe

6 x1pcs   530mm pipe

A x6pcs

F 50mx1

J x1pcs   Roof

H x2pcs

I x3pcs

K x4pcs

L x3pcs

M x10pcs

N xNpcs

O x16pcs

# Step 1

Assemble the bottom frame as the below drawing.

Step 2

Gather pipe "3"×8pcs, insert the pipes into the connectors "C", "D" as the below drawing.

Step 3

Gather connector "A"×4pcs, "B"×4pcs, and pipe "2"×6pcs, assemble as the below drawing.

Step 4

Gather connector "A"×2pcs, "B"×2pcs. Pipe "4"×8pcs and "2"×3pcs
Assemble the top frame as the drawing.

Step 5

Assemble the door with 1 pcs of "D1", 1pcs of "D2", 1 pcs of "D3",
2 pcs of "5" and 1 pcs of "6".

Step 6

Install the door to the chicken frame with "H"x2 pcs,
"I"x3pcs and screws.

Step 7

Step 1: NO PRE-CUT! Cover around the house, then cut off finally.
And tie it to the pipes with strap "N".

Step 8

NO PRE-CUT! Cover the top, finally cut off. And tie it
to the pipes with strap "N".

Step 9

Measure the △parts of front and back sides, Pre-cut the wire mesh
for covering . And tie it to the pipes with strap "N".

(Front)   (Back)

Step 10

Measure the door size, Pre-cut the wire mesh for covering . And tie it
to the pipes with strap "N".

Step 11

Put the waterproof cover "J" on the frame, tighten it on the frame with "O".

Step 12

Put the ground anchor "M" into ground to make the cage more stable and durable.